

Fisher-Price®

**Baby
Smartronics™**

Jivin' Jukebox™

Instructions

Model 71664



Please keep these instructions for future reference.


Requires three "AA" batteries (included).

Tool needed for battery replacement: Phillips screwdriver (not included).

www.fisher-price.com

Battery Replacement

For best results, use only alkaline batteries.




SHOWN ACTUAL SIZE

For best performance, we recommend replacing the batteries that came with this toy with three, new **alkaline** batteries.

Battery Tips

- Do not mix old and new batteries.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries during long periods of non-use. Always remove exhausted batteries from the toy. Battery leakage and corrosion can damage this toy. Dispose of batteries safely.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended in the "Battery Replacement" instructions are to be used.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before they are charged.
- If you use a battery charger, it should be examined regularly for damage to the cord, plug, enclosure and other parts. Do not use a damaged battery charger until it has been properly repaired.



- Loosen the screw in the battery compartment door with a Phillips screwdriver. (The screw will remain in the door.)
- Lift to remove the battery compartment door.
- Insert three "AA" (LR6) **alkaline** batteries as indicated inside the battery compartment.


Helpful Hint: We recommend using alkaline batteries for longer battery life.

- Replace the battery compartment door and tighten the screw with a Phillips screwdriver. Do not over-tighten.
- When sounds from this toy become faint or stop working, it's time for an adult to replace the batteries!


Let's Listen and Learn


The Jivin' Jukebox™ has two modes: Numbers and Letters and Colors and Shapes.

Numbers and Letters Mode




Mode Switch in TOP Position





- To learn numbers and letters, slide the mode switch to the top position .
- Press any of the number keys to hear a number as well as short song and dancing lights.
- Press any of the letter keys to hear a letter as well as short song and dancing lights.
- Spin the roller to hear a friendly tune. Lights flash as the music plays!
- To turn the Jivin' Jukebox™ off, slide the mode switch to the middle position • .

Colors and Shapes Mode






Mode Switch in BOTTOM Position



- To learn colors and shapes, slide the mode switch to the bottom position .
- Press any of the shape keys to hear a shape as well as short song and dancing lights.
- Press any of the color keys to hear a color as well as short song and dancing lights.
- Spin the roller to hear a friendly tune. Lights flash as the music plays!
- To turn the Jivin' Jukebox™ off, slide the mode switch to the middle position • .

Adjusting the Volume



- Locate the volume switch on the back of the toy.
- Select low volume  or high volume .

Care

- Wipe this toy with a clean cloth dampened with a mild soap and water solution. Do not immerse this toy.
- This toy has no consumer serviceable parts. Please do not take this toy apart.

FCC Note

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-KIDS**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

If you have any questions about this product:

In Canada, call 1-800-567-7724, or write to: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

In Great Britain, telephone 01628 500303.

In Australia, call the Fisher-Price Australian Consumer Advisory Service toll-free at 1-800-800-812, or write to: Mattel Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond Victoria, 3121 Australia.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2000 Mattel, Inc. All Right Reserved. ® and ™ designate
U.S. trademarks of Mattel, Inc.