

Fisher-Price®

Instructions

Product Number: 73409

**Baby
Smartronics™**

High Flyin'® Language Learner™



**Please keep this instruction sheet for future reference,
as it contains important information.**

Requires three "AA" batteries (included).


Adult assembly is required for battery replacement.

Tool required for battery replacement: Phillips screwdriver (not included).

www.fisher-price.com

Battery Replacement

For best performance, we recommend replacing the batteries that came with this toy with three, new alkaline "AA" (LR6) batteries.



- Locate the battery compartment door on the bottom of the toy.
- Loosen the screws in the battery compartment door with a Phillips screwdriver.
- Remove the battery compartment door.
- Insert three "AA" (LR6) **alkaline** batteries, as indicated inside the battery compartment.

Hint: We recommend using **alkaline** batteries for longer life.

- Close the battery compartment door and tighten the screws with a Phillips screwdriver. Do not over-tighten.
- When sounds or lights from this toy become faint or stop, it's time for an adult to change the batteries!


Battery Tips




- Do not mix old and new batteries.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries during long periods of non-use. Always remove exhausted batteries from the toy. Battery leakage and corrosion can damage this toy. Dispose of batteries safely.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended in the "Battery Replacement" instructions are to be used.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before they are charged.
- If you use a battery charger, it should be examined regularly for damage to the cord, plug, enclosure and other parts. Do not use a damaged battery charger until it has been properly repaired.




Multi-Lingual Learning Fun!


The High Flyin' Language Learner™, with lights, music and fun, introduces baby to three Languages – English, French and Spanish.



- Locate the power/volume switch on the toy.
- The switch has three positions: off ; on with low volume  and on with high volume .

- Locate the language selector switch on the toy.
- Slide the switch to one of three positions: French **Français**, English **English** or Spanish **Español**. You'll hear a greeting in that language.





Animals – The cat speaks French; the monkey speaks English; and the dog speaks Spanish.

Hint: If you press an animal that does not speak the language selected, it will make a sound.

Display Window – Shows any of five numbers, five foods and five animals.

Propeller – Spin the propeller to change the pictures in the display window. Listen for the airplane and watch the lights!

Learning Buttons – Press the button under the picture in the display window. The picture lights up and the animal identifies the picture in the language selected.

In French, the cat says: “**trois**”.

In English, the monkey says: “**three**”.

In Spanish, the dog says: “**tres**”.

Music Button – Press this button at any time to hear a fun tune and see dancing lights. There are nine different songs!



Care

- Wipe this toy with a clean cloth dampened with a mild soap and water solution. Do not immerse this toy.
- This toy has no consumer serviceable parts. Do not take this toy apart.

FCC Note (United States Only)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-KIDS**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to:

Fisher-Price® Consumer Relations
636 Girard Avenue
East Aurora, New York 14052

For other countries outside the United States:

Canada: call **1-800-567-7724**, or write to: Mattel Canada Inc, 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

Great Britain: telephone 01628 500303.

Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.

©2001 Mattel, Inc. All Right Reserved. ® and ™ designate

U.S. trademarks of Mattel, Inc.

