



- Remove the two #6 x 1/2" screws from the activity panel on the dash. Set the #6 x 1/2" screws aside for re-assembly.
- Lift to remove the activity panel from the dash.
- Insert and snap the radio knobs into the activity panel, as shown.
- From the back side of the activity panel, insert a #12 x 1" screw into the end of each radio knob.
- While holding the radio knobs in place, tighten the screws with a Phillips screwdriver. Do not over-tighten.
- Fit the tabs on the bottom of the activity panel into the notches in the dash opening, as shown.
- Replace the #6 x 1/2" screws through the holes in the activity panel and into the dash. Tighten the screws with a Phillips screwdriver. Do not over-tighten.