



Billy Blazes™

Model Number: B3058

Please keep this instruction sheet for future reference,
as it contains important information.

Requires three "AAA" batteries (included).


Adult assembly is required for battery replacement.

Tool required for battery replacement:
Phillips screwdriver (not included).

Fisher-Price®

www.rescueheroes.com

BATTERY REPLACEMENT




For best results we recommend replacing the batteries that came with this toy with three, new "AAA" (LR03) alkaline batteries.

- Remove the backpack from the figure.
- Locate the battery compartment on the backpack.
- Loosen the screw in the battery compartment door with a Phillips screwdriver. Remove the battery compartment door. Throw the exhausted batteries away.
- Insert three "AAA" (LR03) **alkaline** batteries, as indicated inside the battery compartment.

***Hint:** We recommend using **alkaline** batteries for longer life.*

- Replace the battery compartment door and tighten the screws with a Phillips screwdriver. Do not over-tighten.

BATTERY SAFETY INFORMATION




SHOWN ACTUAL SIZE

Batteries may leak fluids that can cause a chemical burn injury or ruin your toy. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the toy. Dispose of batteries safely. Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

ATTACHING THE BACKPACK



- Slide the backpack onto the connector on back of the figure, as shown.

BILLY HAS A REAL WORKING MEGAPHONE!



- Press the left button on the backpack to hear Billy say one of several phrases.

- Press the right button and speak into Billy's backpack. Your voice comes through the megaphone!



CARE

Figure

- Wipe this toy with a clean cloth dampened with a mild soap and water solution.
- Do not immerse this toy.

Coat

- Machine wash the coat on a gentle cycle. Do not use bleach. Tumble dry on low heat.

FCC NOTE (UNITED STATES ONLY)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

CONSUMER INFORMATION

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-5437**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470.

Or, write to: Fisher-Price® Consumer Relations,
636 Girard Avenue, East Aurora, New York 14052.

For countries outside the United States:

CANADA

Questions? 1-800-567-7724, Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

GREAT BRITAIN

Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB.

Helpline: 01628 500302.

AUSTRALIA

Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

NEW ZEALAND

16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA

Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Fisher-Price, Inc., a subsidiary of Mattel, Inc. East Aurora, New York 14052, U.S.A.

©2003 Mattel, Inc. All Rights Reserved.

® and ™ designate U.S. trademarks of Mattel, Inc.