


Please keep this instruction sheet for future reference, as it contains important information.

Age: Birth to 5 months.

Adult assembly is required.

Requires four "D" (LR20) **alkaline** batteries for the mobile and two "AA" (LR6) **alkaline** batteries for the remote (batteries not included).

Tool needed for assembly: Phillips screwdriver (not included).




Consumer Information

WARNING

Possible entanglement injury.

- Keep out of baby's reach.
 - Remove mobile from crib or playpen when baby begins to push up on hands or knees.
 - This product will not attach to all crib/cot designs. Do not add additional strings or straps to attach to a crib or playpen.
-
- A crib mobile is intended for visual stimulation and is not to be grasped by a child.
 - When used on a dresser top, do not place within the reach of a standing baby.
 - Always attach by all provided fasteners (clamp) tightly to a crib or playpen according to the instructions. Check frequently.

Assembled Parts




Assembly

CAUTION


This toy contains small parts in its unassembled state. Adult assembly is required.

1



- Insert and “**snap**” the tabs on the ends of the butterfly spokes into the slots in the hub, as shown.


2




- Place the end of the spoke with the larger hole onto the matching hole on the hub, as shown.
- Insert a #4 x $\frac{3}{8}$ " screw through the spoke and into the hub and tighten.
- Repeat this procedure to attach the other two soft toy spokes.

Assembly

3



- Fit a soft toy string through the slot in the end of a soft toy spoke.
- Pull down gently on the soft toy to secure the string in the soft toy spoke.
- Repeat this procedure to attach the remaining soft toys to the other two soft toy spokes.



4


- Insert and “snap” the arm into the hole in the side of the hub.
- Fit the arm into the slot in the base, as shown.
- Insert the #6 x $\frac{5}{8}$ ” screw through the arm and into the base. Tighten the screw.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.

©2008 Mattel, Inc. All Rights Reserved. © and ™ designate U.S. trademarks of Mattel, Inc.

Battery Installation

Hint: We recommend using **alkaline** batteries for longer battery life.



Mobile Base

- Loosen the screws in the battery compartment door. Remove the battery compartment door.

Hint: If the crib adapter is attached to the base, loosen the screws in the crib adapter and remove it first.

- Insert four "D" (LR20) **alkaline** batteries.
- Replace the battery compartment door and tighten the screws.

IMPORTANT! Under normal use conditions, the batteries in the mobile will require replacement more often than the batteries in the remote. When sounds or light become faint or movement of the mobile is sluggish, it's time for an adult to replace the batteries in the mobile base.

Remote


- Loosen the screw in the battery compartment door. Remove the battery compartment door.
- Insert two "AA" (LR6) **alkaline** batteries.
- Replace the battery compartment door and tighten the screw.

IMPORTANT! If the mobile does not respond to the remote, it does not mean that the battery power in the remote is low. Replace the batteries in the remote if the LED signal indicator on the remote is dim when the button is pressed. If the LED signal indicator does not light after installing new batteries in the remote, check the orientation of the batteries in the battery compartment to make sure they are properly installed.



- Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities (Europe only).

Battery Safety Information





In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the product. Dispose of batteries safely. Do not dispose of product in a fire. The batteries inside may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.


Crib Setup

1



- Position the base so that the battery compartment door is facing you.
- Fit the crib adapter onto the base. Tighten the screws in the crib adapter.



2



- Fit the mobile base on to the crib top rail so that the threaded peg extends outside of the crib.
- Fit the clamp onto the threaded peg and turn the clamp clockwise to secure the base to the crib rail. Do not over-tighten the clamp.
- If the distance between the base and the mattress is less than 7 inches, lower the crib mattress.


Dresser Top Setup

1



- Loosen the screws in the crib adapter.
- Lift and remove the crib adapter.
- Store the crib adapter in a safe place for future crib use.

Dresser Top Setup




2

- Pull the knob on the arm out. Rotate the mobile portion of the arm down. Release the knob to lock the arm in position.
- Place the mobile on a dresser top out of reach of baby.

Use


IMPORTANT!

- In the unlikely event that use of the remote interferes with normal use of other remote controlled equipment, such as televisions and stereos, or use of other electric or battery powered appliances interfere with operation of the mobile, do not use both appliances at the same time.
- For best performance between the mobile and the remote, avoid using the remote in areas of bright light. In bright natural or artificial light, you may notice loss of range. Move the mobile or reduce the amount of light to improve performance.




- When using the remote, make sure that the arrow on the mobile dome is pointing towards the transmitter window on the remote. **For best results, make sure the path between the transmitter window on the remote and the mobile dome are in a direct line and free of obstacles. Rotate the mobile dome so that the arrow points to the area from which you're most likely to use the remote.** For example, if you'll most often be using the remote from the doorway of the nursery, make sure that the arrow on the mobile dome is pointing towards the doorway and that the path between the mobile dome and the doorway is free from obstructions.

Use




Power/Volume Switch

- The switch has four positions: off ○; on with low volume 🔊, on with high volume 🔊 or no sound 🚫 (lights only).
- Slide the power/volume switch to the off position ○ when not in use.




Song Select Button

- Press the button to choose from six different songs.
- Each time you press the song select button, the mobile will switch to the next of the selections until it returns back again to the first.




Light Select Button

- Press the button to choose from four different light modes:
 - Light the dome and project butterflies and leaves on baby's ceiling.
 - Light the night light with soft, glowing colors.
 - Light both the dome and night light.
 - Turn lights off (music only).
- Each time you press the light select button, the mobile will switch to the next of the four modes until it returns back again to the first.



Start Button

- Press the start button on either the mobile or the remote to activate music and lights.
- The mobile plays for approximately five minutes.
- To restart the mobile, press the start button again.



Consumer Information


FCC Statement (United States Only)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.





Soft Toys

- To remove a soft toy, grasp its string and press the knot up through the opening in the spoke.
- The soft toys are surface washable.

Mobile

- Wipe the toy with a clean cloth dampened with a mild soap and water solution. Do not immerse the toy.

**CONSUMER ASSISTANCE**
Call toll free: 1-800-432-5437 (US & Canada only)
M-F 9AM to 7PM / SAT 11AM to 5PM (EST)

 **service.fisher-price.com**

Write to us at: Fisher-Price® Consumer Relations,
636 Girard Avenue, East Aurora, New York 14052.

Hearing-impaired consumers using TTY/TDD equipment,
please call 1-800-382-7470.

For countries outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel.UK.Ltd.Vanwall.Business.Park,
Maidenhead SL6 4UB, Helpline: 01628 500303,
www.service.mattel.com/uk

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.
Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.

Asia: Mattel East Asia Ltd, Room 1106, South Tower,
World Finance Centre, Harbour City, Tsimshatsui, HK, China.