

BATTERY INSTALLATION

Unscrew and lift cover away from top of Percy.
Install battery as indicated inside the battery compartment.
For longer life use only alkaline batteries.
Requires 1 "AA" (LR6) battery.
If this toy begins to operate erratically, you may need to reset the electronics.
Remove the batteries from the toy and replace it.

BATTERY SAFETY INFORMATION




- In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:
- Non-rechargeable batteries are not to be recharged.
 - Rechargeable batteries are to be removed from the product before being charged.
 - Rechargeable batteries are only to be charged under adult supervision.
 - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
 - Do not mix old and new batteries.
 - Only batteries of the same or equivalent type as recommended are to be used.
 - Batteries are to be inserted with the correct polarity.
 - Exhausted batteries are to be removed from the product.
 - The supply terminals are not to be short-circuited.
 - Dispose of battery(ies) safely.
 - Do not dispose of this product in a fire.
- The batteries inside may explode or leak.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
- THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.
 - CET APPAREIL NUMERIQUE DE LA CLASSE B EST CONFORME A LA NORME NMB-003 DU CANADA.
- Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- L'utilisation de ce produit est sujette aux conditions suivantes :
- (1) il ne doit pas produire de brouillage et
(2) il doit pouvoir tolérer tout brouillage reçu, même si ce brouillage est susceptible de compromettre son fonctionnement.

Required tool:
Phillips screwdriver
(not included)




ID: Y2024-0920



REPTILE PARK SET

ASSEMBLY INSTRUCTIONS

Please keep these instructions for future reference as they contain important information.



ADULT ASSEMBLY REQUIRED. No tools required for assembly.

CONSUMER ASSISTANCE
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)
service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:
Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.
Great Britain: Mattel UK Ltd, Vauxhall Business Park,
Maidenhead SL6 4UB; Helpline: 01628 500303.
www.service.mattel.com/uk
Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.
Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.
New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.

Thomas the Tank Engine & Friends™

CREATED BY BRIT ALLCROFT

Based on the Railway Series by The Reverend W Awdry.

©2012 Gullane (Thomas) Limited.

Thomas & Friends are trademarks

of Gullane (Thomas) Limited.

© HIT Entertainment Limited.

HIT and the HIT logo are trademarks

of HIT Entertainment Limited.

©2012 Mattel. All Rights Reserved.

® and ™ designate U.S. trademarks of Mattel,

except as noted. **PRINTED IN CHINA.**

Mattel East Asia Ltd., Room 1106, South Tower,

World Finance Centre, Harbour City,

Tsimshatsui, HK, China.

CAUTION:
To prevent entanglement,
keep hair away from wheels.

MAY NOT WORK WITH ALL ENGINES.


Protect the environment by not
disposing of this product with
household waste (2002/96/EC).
Check your local authority for recycling
advice and facilities.




Y2024
R9489 Asst.

Fisher-Price

TRACK LAYOUT




LABEL POSITION




HOW TO PLAY


1 As the engine passes the reptile park...




2 ...it will trigger the gate to open
and the reptile will escape!



3



HOW TO RESET



You can also release the reptile
by pressing the rock.

Item No : Y2024-0920
Version : EL
Size : 16.54" x 11.69" (A3)
Paper : Woodfree paper 70 gsm
Color : Black
Date : Aug 30, 2012 (Vita)