

## Fisher-Price® Trikes Recall

There has been a recall announcement for these products.

Mattel, in cooperation with relevant safety regulators are voluntarily recalling a number of Fisher-Price® Trikes and Tough Trikes toddler tricycles. These trikes are intended for children 2 to 5 years of age. They include pretend keys that are located about 3 inches in front of the seat and protrude at least 5/8 inches above the trike's body.

**A child can strike, sit or fall on the protruding plastic ignition key resulting in serious injury**

**This recall does not include Lights and Sounds Trikes; Rock, Roll 'n Ride Trike; Grow-With-Me Trikes; Action Sounds Trike; Push 'n Pedal Trike. These Trikes do not have a key feature in front of the seat. Any Fisher-Price® Trike with a key located on the handle bars is not affected by this recall.**

Use this online guide to determine if the product you own is affected by this recall. Please have your product near you as you continue.

### MODELS INCLUDED IN THIS RECALL

The model numbers are located under the seat in the storage compartment.

<b>B8775 Kawasaki Tough Trike</b>		<b>B8776 Barbie™ Tough Trike</b>	
<b>K6672 Nick Jr. Dora the Explorer Tough Trike</b>		<b>K6673 Go Diego Go!™ Tough Trike</b>	
<b>N6021 Kawasaki Tough Trike</b>			

If you do not own one of the trikes shown in the images above, you are **not** affected by this recall and you can continue to enjoy your trike.

If you own one of the trikes shown in the images above or you are not sure if you own one of the trikes shown in the images above, please locate the key on your Fisher-Price® Trike.



If the key on your trike is located anywhere other than about 3 inches in front of the seat and protrude at least 5/8 inches above the trike frame, you are **not affected** by this recall and you can continue to enjoy your trike.

If the key on your trike is located about 3 inches in front of the seat and protrude at least 5/8 inches above the trike frame, please look at the shape of the key.



If your trike's key is a flattened D-shaped key shown in the image you are **not affected** by this recall and you can continue to enjoy your trike



If your trike's key is a Disc-shaped key shown in the image you **are affected** by this recall.

**Please discontinue using the Trike(s) immediately.**



If your trike's key is a D-shaped key shown in the image you **are affected** by this recall.

**Please discontinue using the Trike(s) immediately.**

If your product is affected by this recall or if you have any questions in regards to this recall, please contact Fisher-Price at (+603-33419052) between 9 a.m. and 6 p.m. Monday through Friday or visit the firm's website at [service.mattel.com](http://service.mattel.com).