NIGHT PATROL™

Pat Pending™

Scientist



Model Number: 78196

Please keep this instruction sheet for future reference,
as it contains important information.
Requires three "LR44" **alkaline** button cell batteries (included).
Adult assembly is required for battery replacement.
Tool required for battery replacement:
Phillips screwdriver (not included).

Fisher-Price®


www.rescueheroes.com

READY FOR ACTION!



Press the button on the figure's backpack to see his welding torch flicker and pack light up.


Backpack/Robot



Backpack transforms into a robot!

- Slide the backpack off the figure. Place the torch handle into the hole in the side of the backpack.
- Grasp the top of the backpack/robot to lift it from its base. It's a robot!
- The robot can be posed in different positions.
- Press the button on the robot's back to see it's eyes and tool light up.

BATTERY REPLACEMENT



- When lights from this toy become faint or stop, it's time for an adult to change the batteries!
- Locate the battery compartment door on the backpack/robot.
- Loosen the screw in the battery compartment door with a Phillips screwdriver. Remove the battery compartment door.
- Insert three, button cell (LR44 or equivalent) **alkaline** batteries, as indicated inside the battery compartment.

Hint: *We recommend using* ***alkaline*** *batteries for longer battery life.*


- Replace the battery compartment door and tighten the screw with a Phillips screwdriver. Do not over-tighten.

CARE

- Wipe the toy with a clean cloth dampened with a mild soap and water solution.
- Do not immerse the toy.

BATTERY TIPS

For best results, use only alkaline batteries.



1.5V x 3
LR44 or equivalent
SHOWN ACTUAL SIZE

- Do not mix old and new batteries.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries during long periods of non-use. Always remove exhausted batteries from the toy. Battery leakage and corrosion can damage this toy. Dispose of batteries safely.
- Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended in the "Battery Replacement" instructions are to be used.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before they are charged.
- If you use a battery charger, it should be examined regularly for damage to the cord, plug, enclosure and other parts. Do not use a damaged battery charger until it has been properly repaired.

Fisher-Price, Inc., a subsidiary of Mattel, Inc. East Aurora, New York 14052, U.S.A.
©2002 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

Printed in China **78196pr-0920**

FCC STATEMENT (UNITED STATES ONLY)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

CONSUMER INFORMATION

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-KIDS,** 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

For other countries, outside the United States: **Canada:** call **1-800-567-7724**, or write to: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.
Great Britain: telephone 01628 500302.
Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.
New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

COLLECT THE OTHER MEMBERS OF THE NIGHT PATROL™ TEAM!

Each sold separately and subject to availability.



Captain Cuffs™
Police Officer
78193



Sam Sparks™
Firefighter
78194



Sergeant Siren™
Police Officer
78195



Aidan Assist™
Emergency Medical Technician
78306



Willy Stop™
Police Officer
78319