



Note!

- We've included extra fasteners that you will not use for assembly of this vehicle.
- This vehicle requires:
 - 16** - #10 x $\frac{3}{4}$ " Screws
 - 6** - #8 x 1" Screws
 - 2** - #8 x 4" Screws
 - 2** - #8 x 1.625" Screws
 - 2** - #8 Acorn Lock Nuts
 - 2** - .354 Cap Nuts

After assembly is complete, please throw away all extra fasteners.