

Fisher-Price®

www.fisher-price.com













K7113




GeoTrax
Rail & Road System

Parts



- A. Conveyor
- B. Chute
- C. Loader
- D. Spiral
- E. Quarry Base
- F. 2 Quarry Walls
- G. Spiral Support
- H. Rock Base
- I. Dump Station
- J. Turn Off Track
- K. 2 Boulders
- L. Dump Truck
- M. 2 Curved Tracks
- N. Double Curve Track
- O. Small Ramp



Assembly




"Snap" both quarry walls to the quarry base.





"Snap" the spiral support to the tabs on the quarry walls, as shown.

Assembly




- First, “snap” the peg on the outside of the loader into the hole in the quarry wall **A**.
- Then, “snap” the handle base on the loader into the groove in the quarry wall **B**.

Beginning at the wide of the spiral, “snap” the spiral onto the posts on the quarry walls.



“Snap” the conveyor into the rock base.

Try these Layouts



Lift and Load



- Turn the crank on the conveyer to move boulders to the top of the spiral.
- Watch boulders roll down the spiral and into the chute.
- Tip the loader back to catch the boulder, and then forward to load it into the dump truck.

Fast Dumping Action



- Push the dump truck along the track.
- Back the dump truck up to the dumping station and the boulder drops in.

The Fisher-Price logo is displayed in white text within a dark blue, cloud-like shape.

Visit www.fisher-price.com to see the entire world of GeoTrax[®] accessories!

**Please keep this instruction sheet for future reference,
as it contains important information.**

Adult assembly is required.

No tools needed for assembly.

Wipe the toy with a clean, damp cloth. Do not immerse.

Visit us on line at www.service.fisher-price.com.

Call our Consumer Relations Department, toll-free at **1-800-432-5437**,
9 AM - 7 PM EST Monday through Friday and 11 AM - 5 PM EST Saturday.

Hearing-impaired consumers using TTY/TDD equipment,
please call 1-800-382-7470.

Write to us at:

Fisher-Price[®] Consumer Relations
636 Girard Avenue, East Aurora, New York 14052

For countries outside the United States:

CANADA: Questions? 1-800-432-5437. Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2;
www.service.mattel.com.

GREAT BRITAIN: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB.
Helpline: 01628 500303; www.service.mattel.com/uk.

AUSTRALIA: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.
Consumer Advisory Service 1300 135 312.

NEW ZEALAND: 16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA: Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.