




Mega Mall



INSTRUCTIONS

CONTENTS



CONSUMER INFORMATION

Need Assistance? Visit service.mattel.com or call 1-800-524-8697 (US and Canada only), M-F 9AM - 7PM & SAT 11AM - 5PM, Eastern.

SERVICE.MATTEL.COM

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697.
 Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB, Helpline 01628 500303.
 Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.
 Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.
 Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ.
 Tel:03-78803817, Fax:03-78803867.
 Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Affairs 1 (800) 524-8697.

WARNING:
 CHOKING HAZARD - Small parts.
 Not for children under 3 years.




Please remove everything from the package and compare to the contents shown here.
 If any items are missing, please call 1-800-524-8697.

Keep these instructions for future reference as they contain important information.

3 floors and 9 stores to discover! Hang out with your friends and have the coolest day ever!


ASSEMBLY

The card and 2 signs can be removed.




LET'S PLAY


1 Set the elevator all the way to the top, as shown.




2 Make sure the playset is completely closed up, as shown here.




3 Push the card into the slot. You can also press the button.




4 Open the elevator door, put the doll in and move the elevator up and down to different mall floors.



5 Put the ice skates on the doll, place the ice skate disk in position as shown. Use the thumbwheel to turn and twirl the doll.



NOTE: The disk with the ice skate can be removed when closing up the mall for storage.



10+ places to shop & play!

- | | | |
|---------------|---------------------|------------------|
| 1. Sweet Shop | 5. Dress Shop | 9. Salon |
| 2. Café | 6. Accessories Shop | 10. Photo Studio |
| 3. Skate Shop | 7. Pet Store | 11. Elevator |
| 4. Ski Shop | 8. Music Store | 12. Courtyard |

