

HotWheels INSTRUCTIONS
JURASSIC STARTER SET™

Please keep these instructions for future reference as they contain important information.

CONTENTS

4+ N4730-0920

WARNING:
 CHOKING HAZARD - Small parts.
 Not for children under 3 years.

PINK RUBBER BAND
 ORANGE RUBBER BAND

© 2008 Mattel, Inc. All Rights Reserved.

TO PLAY

Note: All Green buttons are launch buttons.

More Ways To Play

REPLACE RUBBER BAND

ADULT SUPERVISION REQUIRED.

PINK RUBBER BAND

-
-
-

SABRE-TOOTHED STUNT

ORANGE RUBBER BAND

-
-
-

RAPTOR STUNT

Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Relations 1 (800) 524-8697 service.mattel.com • Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697. • Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB, Helpline 01628500303 • Mattel Australia Pty., Ltd., Richmond, Victoria, 3121. Consumer Advisory Service - 1300 135 312. • Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. • Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd (993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ, Tel: 03-78803817, Fax: 03-78803867.

To view instructions online go to: www.hotwheels.com/instructions.

ASSEMBLY

GET READY TO PLAY

-
-