

Safety Recall

Fisher-Price® 3 in 1 High Chair to Booster™
Model Number: P6028

Sold Since: 9 February, 2009

Fall Hazard



Falls can occur if booster seat release is unlatched while child is in the product, or if the seat back is not snapped in. Contact Fisher-Price for a free repair kit.

Call Fisher-Price for more information.

01628 500303

www.service.mattel.com/uk

To be posted through July 2009

Fisher-Price®

In cooperation with European Regulatory Authorities