

## CONSUMER INFORMATION

MATTY MATTEL™ Toys



YOU CAN TELL IT'S MATTTEL! CALL us toll-free or write with any comments or questions about our products or service. Monday-Thursday, 8:00 a.m.-5:00 p.m. PST; 11:00 a.m.-8:00 p.m. EST; Friday, 8:00 a.m.-12:30 p.m. PST, 11:00 a.m.-3:30 p.m. EST. Outside U.S.A., see telephone directory for Mattel listing. Consumer Affairs, Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 USA

**1 (800) 524-TOYS**



CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

We are dedicated to quality products.

## 2 YEAR LIMITED WARRANTY


Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material or workmanship for two years (unless specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Adjustment Center, 15930 E. Valley Boulevard, City of Industry, California 91744 for replacement or refund at our option. This warranty does not cover damage resulting from accident, misuse, or abuse. **Valid only in U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Send only the product to the address above. Send all correspondence to Consumer Affairs, Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245-5012, U.S.A. Or you may phone us toll-free at 1-800-524-TOYS, Monday through Thursday: 8:00 a.m.-5:00 p.m. PST (11:00 a.m.-8:00 p.m. EST); Friday: 8:00 a.m.-12:30 p.m. PST (11:00 a.m.-3:30 p.m. EST).



## Instructions

### Contents:



Please remove everything from the package and compare to the contents shown here.

If any items are missing, please call 1-800-524-TOYS.


Keep these instructions for future reference as they contain important information.

Diapers are for use with 12" to 14" Cabbage Patch Kids® only.

Accessories are for doll only. They are not intended for real infant or child use.

Mattel, Inc., El Segundo, CA 90245 U.S.A. ©1998 ORIGINAL APPALACHIAN ARTWORKS, INC. ALL RIGHTS RESERVED.  
Kellogg Company characters and trademarks are used under license and with permission of Kellogg Company.™, © 1998 Kellogg Company. Nestlé® and Raisinets® are registered trademarks used with the consent of Nestlé USA, Inc.


## Add Batteries



1.



2.



3. Unscrew compartment cover with Phillips screwdriver (not included) and lift cover to open.
- NOTE:** Screw will remain attached to cover. Install 3 "AA" alkaline batteries in compartment as shown. Replace battery compartment cover.

Requires 3 "AA" batteries, not included. Use only alkaline batteries.  
Replace batteries when voice fades or becomes garbled.

### CAUTION: To avoid battery leakage:


1. Non-rechargeable batteries are not to be recharged.
2. Do not use rechargeable batteries.
3. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
4. Never mix old batteries with new batteries (replace all batteries at the same time).
5. Be sure to insert batteries with the correct polarities and always follow the toy and battery manufacturers' instructions.
6. Remove batteries from product before extended storage.
7. Always remove old or dead batteries from the product.
8. The supply terminals are not to be short-circuited.
9. Check that the contact surfaces are clean and bright before installing batteries.

## It's Play Time!

I say 6 different phrases!  
"Yum-yum!", "No more!",  
"Mmmmm, good!", Giggle,  
"Uh-uh!", "Yeah!"

When you  
"feed" me, press  
my tummy to hear  
how I like my food!

...When I like  
something, I wave  
my arms!



...When I don't like  
something, I shake  
my head NO!



SPOON AND BOWL ARE NOT DISHWASHER OR MICROWAVE SAFE.  
SURFACE WASHABLE ONLY.