

Colors and decorations may vary.


26445-0920


Please remove everything from the package and compare to the contents shown here. If any items are missing, please call 1-800-524-TOYS. *Keep these instructions for future reference as they contain important information.* 




© 2000 Mattel, Inc., El Segundo, CA 90245 U.S.A. All Rights Reserved.

## **Unfold House**







## **Raise and Lower Elevator** Swing ramp down and lower handle. Turn handle to raise Raise handle. and lower elevator. Storage Swing crib back against wall. Close ramp, lower elevator Fold up floors and re-insert handle. and sides. Shut kitchen doors. Fold up Close latch. bed. Fold tub up into wall.

## www.barbie.com

## **2 YEAR LIMITED WARRANTY**

Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material or workmanship for two years (unless specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Adjustment Center, 15930 E. Valley Boulevard, City of Industry, California 91744 for replacement or refund at our option. This warranty does not cover damage resulting from unauthorized modification, accident, misuse, or abuse. **Valid only in U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Send only the product to the address above. Send all correspondence to Consumer Relations, Mattel, Inc., 333 Continental Blvd., El Segundo, California 90245-5012, U.S.A. Or you may phone us toll-free

at 1-800-524-TOYS, Monday - Friday, 8:00 a.m. - 6:00 p.m. Eastern Time. See telephone directory for Mattel listing.



