

# TYCO® Elmo's 1-2-3 Sprinkler™



## INSTRUCTION SHEET


Dear Parents: Thank you for purchasing Elmo's 1-2-3 Sprinkler. Elmo's 1-2-3 Sprinkler has been designed for use with standard garden hoses and has a variety of spray patterns that can be selected to provide hours of fun.

### • CAUTION •

Water inside of Elmo's 1-2-3 Sprinkler or your garden hose, which is left for an extended period of time outside in direct sunlight, can become very hot and can harm your child. We recommend that you drain the 1-2-3 Sprinkler and your garden hose after each use and then store them in a cool, shaded area.

**Note:** Spray patterns can be changed with water supply ON or OFF.

### How to attach to a Garden Hose




1. Insert the garden hose end into the hose inlet on back of Elmo's 1-2-3 Sprinkler, and rotate the hose inlet until tight, in the direction shown in the diagram. **Do not over tighten.**

2. Slowly turn water supply "ON" (at the spigot), after choosing spray pattern.

**Note:** For best performance, use just enough water pressure to make the water spray up and/or Elmo spin.

### How to operate the Selector Knob


PRESS DOWN ON  
SELECTOR KNOB &  
TURN LEFT OR RIGHT



- A. To select spray patterns, press Selector Knob "DOWN" and turn left or right to the desired spray pattern.
- B. The arrow on top of "Selector Knob" shows which position the Knob is pointing to.

## How to select the 3 Stages


### Baby Stage ①




When knob is turned to No.1 selection, Elmo's snorkel sprays a gentle mist that keeps babies cool.




### Toddler Stage ②




When Knob is turned to No.2 selection, three water streams squirt from Elmo's inner tube as he spins and snorkel sprays mist.



### Preschool Stage ③



When Knob is turned to No.3 selection, Elmo's Clam Pal gets into the fun by squirting a stream of water, spinning Elmo faster, and squirting water everywhere.



Please read instructions on back, if the 1-2-3 Sprinkler tips over during play!

ITEM NO. 36173




# How to assemble the Support Legs (Optional)

**Dear Parents:** If your 1-2-3 Sprinkler is tipping over during play, it might require the attachment of the Support Legs (included) to the bottom of Elmo's Sprinkler as explained below. The support legs will help prevent the sprinkler from tipping over.

## Step 1

- A.** Locate the (3) Support Legs and arrange them around Elmo's 1-2-3 Sprinkler.

**Note:** The Post end of the Legs should face inward toward the Sprinkler, as shown.




## Step 2

- A.** Attach Support Legs under the Base of the Sprinkler. Notice that the Cross shaped Posts on Legs fit into the Holes, as shown in inset drawing.

**Note:** Firmly press the Posts into the Holes.

- B.** Place the Sprinkler on a level area and have fun.



**THANK YOU!**

From Children's Television Workshop

The money that CTW receives when you buy a Sesame Street product is put right back into Sesame Street and other CTW educational projects. CTW is a not-for-profit organization.