



***Rider***



# ***Team McDonald's***<sup>®</sup>



Model Number: 72658

Please save these instructions for future reference.  
Adult assembly is required.  
No tools needed for assembly.  
For ages 12 to 36 months and up to 40 lbs. (18 kg).



# Label Decoration

- Wipe the areas where the labels will be applied with a clean, dry cloth.
- Wash your hands before applying labels to the vehicle.
- Apply labels as indicated in the illustrations.
- Avoid repositioning a label once it has been applied.




# Assembly

## WARNING

- Adult supervision is required.
- Never use near steps, sloped driveways, hills, roadways, swimming pools or other bodies of water.
- Always wear shoes.
- Never allow more than one rider.

## CAUTION

This product contains small parts.  
Adult assembly is required.



- 1**
  - Fit the tabs on the hubcaps into the slots in the wheels.
  - Push firmly to snap the tabs into the slots.
- 2**
  - Fit the steering wheel into the large hole in the vehicle body. Make sure the Fisher-Price® logo on the steering wheel faces the rear of the vehicle body.
  - Press firmly to snap the steering wheel into the vehicle body.
- 3**
  - Fit the tab on the left side of the seat into the hole in the left side of the vehicle body.
  - Align the tab on the right side of the seat with the slot above the hole in the right side of the vehicle body and press firmly to snap the tab into the hole.

## Care and Maintenance

- Periodically check all screws, retainers and protective coverings and tighten as required. Check plastic pieces on a regular basis for cracks or broken pieces.
- To clean or to remove static electricity, wash the vehicle with a mild soap and water solution and soft cloth. Rinse clean with water to remove soap residue and towel dry.

## Consumer Information

Please call Fisher-Price® Consumer Affairs, toll-free at **1-800-432-KIDS**, 8 AM - 5 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Affairs  
636 Girard Avenue,  
East Aurora, New York 14052

[www.fisher-price.com](http://www.fisher-price.com)

If you have any questions about this product:

**In Canada**, call 1-800-567-7724, or write to: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

**In Great Britain**, telephone 01628 500303.

**In Australia**, Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1-800-800-812 (valid only in Australia).

Bill Elliott name and likeness by CMG Worldwide, Indianapolis, Indiana.

©1999 McDonald's Corporation.

The following are Registered Trademarks of McDonald's Corporation: McDonald's; McDonald's Logo and Design; McDonald's Racing Team Logo and Design; Golden Arches Design and McDonald's Drive Thru Crew Logo and Design.

"COCA-COLA" is a trademark of The Coca-Cola Company.

Goodyear (and winged foot design) are trademarks of The Goodyear Tire & Rubber Company, used with permission.

NASCAR is a registered trademark of the National Association for Stock Car Auto Racing, Inc.

Fisher-Price is a registered trademark of Mattel, Inc.

Fisher-Price, Inc., a subsidiary of Mattel, Inc.,  
East Aurora, New York 14052, U.S.A.  
©1999 Mattel, Inc. All Rights Reserved.

Printed in Mexico