



Quick Response™ *Helicopter*

Product Number: 72844




Figure sold separately.


Please save this instruction sheet for future reference,
as it contains important information.

Adult assembly is required.

Tool needed for assembly: Phillips Screwdriver.


www.fisher-price.com

Label Decoration



- Make sure the areas where the labels will be applied are clean and dry.
- Apply the labels as indicated in the illustration.
- For best results, avoid applying the labels more than once.

One-time Assembly




- Insert and snap the rectangular tab on the base into the slot in the helicopter.
 - Insert and snap the rounded tab on the helicopter into the hole in the base.
 - Fit the hole in the underside of the blades onto the peg on the helicopter.
- Helpful Hint:** Align the notch in the blades hole with the notch on the helicopter peg.
- Insert a Phillips screwdriver into the hole in the top side of the blades and tighten the screw. Do not over-tighten.
 - Slide the knobs on each side of the windshield into the indents at the top of the helicopter.
 - Snap the tab on the front of the windshield into the slot on the front end of the helicopter.

Helpful Hint: The windshield may have been factory assembled.

One-time assembly is now complete.

To the Rescue



- Pull the retracting rope to rotate the blades.
- Fit any of the Rescue Heroes™ equipment packs (sold separately) to the pack holders on the helicopter base.

Consumer Information

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-KIDS**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

For other countries, outside the United States:

Canada: Call **1-800-567-7724**, or write to: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

Great Britain: telephone 01628 500303.

Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.
Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, New York 14052, U.S.A.
©2001 Mattel, Inc. All rights reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

Printed in China
72844a-0920