


IMPORTANT!

All **three** electrical connections **MUST** be properly made in order for your product to function!

1 Power Harness Connector

Power Button
Harness Connector
(from steering wheel
underneath tractor)




Motor Harness Connector
(underneath tractor)

- You must first connect the steering wheel power button harness connector to the motor harness connector **underneath** the tractor. Please refer to Assembly steps 10 and 11 on page 10 in your Owner's Manual.

2 Bubble Blower Connector

Bubble Blower Connector
(from bubble blower
underneath tractor)




Motor
Harness
Connector
(inside
seating area)

- Next, connect the bubble blower connector (labeled Bubble Blower) to the second motor harness connector (labeled Bubble Blower) **inside the seating area** of the tractor. Please refer to Assembly steps 18 – 20 on page 12 in your Owner's Manual.

3 Motor Harness Connector

Large Motor
Harness
Connector
(inside
seating area)

Large Battery Connector
(from battery inside
seating area)



- Then, connect the third, large motor harness connector to the battery connector **inside the seating area** of the tractor. Please refer to Battery Installation step 3 on page 15 in your Owner's Manual.

*Now, please refer to your Owner's Manual for complete assembly and use instructions.
If you have any questions, please call us toll-free at 1-800-348-0751.*