



For best performance, please follow these tips.

- Keep the cooling drawer frozen so it's always ready to go.
- The color change feature works best at a room temperature of 68° - 74° F.
- As the treats warm back up, the color change gradually disappears.
"Bake" the treats again to change them back.
- As the ice melts in the cooling drawer, color changing will be less visible.
Refreeze the cooling drawer.
- When battery power is low, the fan will slow down and color changing will be less visible. Replace the batteries with fresh **alkaline** batteries as described in the battery installation section of the instructions.
- In colder rooms, some color change decorations may not disappear completely.
Try warming them by running them under warm water.

