


Fisher-Price®

Wendy Waters™ and Smokey™

*It's Wendy Waters™, Firefighter, here to save the day!
Wendy's pal, Smokey™, Fire dog, is always ready to lend a paw!*



- Slide the equipment pack onto the rectangular tab on Wendy's back.
- Position the "water" unit on the equipment pack forward to slide the hand grip into Wendy's hand.
- Pull back handle on the equipment pack to fire "waterblast".
- The ladder extends, rotates and pivots.
- Push the button to extend the ladder.



If you have any questions about this product please call Fisher-Price® Consumer Affairs, toll-free at **1-800-432-KIDS**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Affairs, 636 Girard Avenue, East Aurora, New York 14052.