RESCUE HEROES™

Cliff Hanger™

Air Rescue Specialist

Model Number: 78381
Please keep this instruction sheet for future reference,
as it contains important information.
No assembly is required.

Fisher-Price®

www.rescueheroes.com

FLYIN' TO THE RESCUE!

1

• Push the button to open Cliff's wings.

3

• Use Cliff's skyhook to rescue the figure and fly to safety.

2

• Slide the rescue pack onto the connector on any Rescue Heroes™ figure.

CARE

- Wipe the toy with a clean cloth dampened with a mild soap and water solution.
- Do not immerse the toy.

CONSUMER INFORMATION

Questions? We'd like to hear from you!
Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-KIDS,**
8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers
using TTY/TDD equipment, please call 1-800-382-7470. Or, write to:
Fisher-Price® Consumer Relations, 636 Girard Avenue,
East Aurora, New York 14052.

For other countries, outside the United States: **Canada:** call **1-800-567-7724**, or write to:
Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.
Great Britain: telephone 01628 500302.
Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond,
Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.
New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

THE FLIGHT TEAM™

Each sold separately and subject to availability.

Flight Team™
Rocky Canyon™
Mountain Ranger
78379

Flight Team™
Ariel Flyer™
Pilot & Veterinarian
78380

Flight Team™
Perry Chute™
Rescue Pilot
78382

THE HYDRO TEAM™

Each sold separately and subject to availability.

Hydro Team™
Billy Blazes™
Firefighter
78374

Hydro Team™
Wendy Waters™
Firefighter
78375

Hydro Team™
Bob Buoy™
Coast Guard
78376

Hydro Team™
Gil Gripper™
Scuba Diver
78378