

Carry Strap



IMPORTANT!

Use the fabric handle on this car seat properly!

Please read and understand the instructions on the front and back of this sheet and all the information in the car seat Owner's Manual (located on the underside of the car seat bottom) to use the car seat properly.

Your child's safety depends on you!


Fisher-Price®

Carry Handle




Carry Strap

To Convert to Carry Strap:



- Unfasten the padded grip on the handle. Unfasten the strap from the hook.



- Extend the carry strap to fit you properly.
- **To Shorten the Carry Strap:** Roll the end of the carry strap to the desired length and fit it into the slot in the base.
- **To Lengthen the Carry Strap:** Un-roll the end of the carry strap and fit it into the slot in the base.

Carry Strap



Place the carry strap **over your head** and around one shoulder.

Fisher-Price, Inc., a subsidiary of Mattel, Inc.,
East Aurora, New York 14052, U.S.A.
©2000 Mattel, Inc. All Rights Reserved.
® and ™ designate U.S. trademarks of Mattel, Inc.

Printed in U.S.A.

79050-0921

Carry Handle



To carry baby, simply lift using the padded handle grip.