

Fisher-Price®

Assembly Instructions

Hop, Skip Jumper Reinforcing Strap Kit

Model Numbers: 79144, 79146



WARNING

To prevent serious injury and/or falls:

Your child could fall from this product if the spring breaks. Do not use this product until you have repaired it using this kit.


Kit Parts

No tools required for assembly




IMPORTANT! Enclosed is a reinforcing strap which will keep this product from falling to the floor during use if the spring breaks. Please follow these instructions carefully.

Assembly




- Locate the round ring below the spring on the Hop, Skip Jumper.
- Fit the large loop end of the reinforcing strap through the round ring.




- Insert the opposite end of the reinforcing strap through the reinforcing strap large loop.
- Pull the reinforcing strap completely through the loop to form a knot.

Assembly



- Locate the triangular ring above the spring on the Hop, Skip Jumper.
- Insert the small loop end of the reinforcing strap through the triangular ring.



- Fold the reinforcing strap over.
- Using your fingernail, split the key ring on the reinforcing strap open slightly and insert the small loop end of the reinforcing strap into the key ring.
- Feed the small loop end of the reinforcing strap completely around the key ring.

Assembly is now complete.



If you have further questions regarding the assembly of the reinforcing strap, please call
Fisher-Price® Consumer Relations, toll free at **1-800-233-4004**,
8 AM - 6 PM EST Monday through Friday.
Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470.
Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue,
East Aurora, New York 14052.

Fisher-Price, Inc., a subsidiary of Mattel, Inc. East Aurora, New York 14052, U.S.A.
©2000 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.