


Fisher-Price®

SOOTHING SOUNDS PORTABLE BASSINET

Model Numbers: 79334, 79336



For Soothing Sounds:

- First, slide the switch to select a soothing sound.
 - 🎵 Plays five lullabies.
 - 🌊 Listen to the sea shore (rolling waves).
 - 🌼 Hear nature sounds (crickets and soft chirping).
- Then, press the ON/OFF button to turn soothing sounds on.

Hint: After each soothing sound selection, be sure to press the ON/OFF button again to turn soothing sounds on.