



# 1, 2, 3 Exploring Tree™

## INSTRUCTIONS



Please keep these instructions for future reference as they contain important information.

### BATTERY INSTALLATION

Unscrew and lift away cover from bottom of product.

Replace batteries as shown.

Requires 3 "AA" (LR6) Batteries.



### BATTERY SAFETY INFORMATION



1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the toy before being charged.
3. Rechargeable batteries are only to be charged under adult supervision.
4. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
5. Do not mix old and new batteries.
6. Only batteries of the same or equivalent type as recommended are to be used.
7. Batteries are to be inserted with the correct polarity.
8. Exhausted batteries are to be removed from the toy.
9. The supply terminals are not to be short-circuited.
10. Dispose of battery(ies) safely. Do not dispose of in a fire as batteries may explode or leak.

### HOW TO ASSEMBLE


#### NOTE:

**This is a one-time assembly. Once the 1,2,3 EXPLORING TREE is assembled it cannot be taken apart.**


- Insert the bottom of the tree trunk into the tree base, lining up the corresponding notches. (The rectangular chute on the tree trunk faces up.) Push down until you hear the pieces snap into place.
- Insert the treetop into the top of the tree trunk, lining up the corresponding notches and the rectangular chute. Push down until you hear the pieces snap into place.



- Snap Eeyore into the corresponding (smaller) hole on the tree base.



- Snap Tigger into the corresponding (larger) hole on the tree base.



Now you are ready to play!

### HOW TO PLAY

To begin, be sure the **ON/OFF** switch is in the **ON** position. The **ON/OFF** switch is located on the bottom of the treetop.

From bottom to top, the **1,2,3 Exploring Tree** allows baby's from the youngest stage of sitting up and crawling to standing up to explore with their Hundred Acre Friends.

#### TREE BASE

Basic activities for crawling or tummy time fun!

- Bat-at bouncy Tigger.
- Spin Eeyore's ball.
- Feel and hear the crinkly butterfly wings.
- Hide or store the 3 colored shapes in the secret "put & take" compartment.

#### TREE TRUNK

- Place the 3 colored shapes in their shaped holes, for basic shape sorting.

#### TREETOP

More challenging activities for standing baby!

- Play peek-a-boo with Piglet for sounds and flashing lights.
- Turn Pooh to hear him speak.
- Drop the 3 colored shapes through the chute for sounds and flashing lights.
- Press the music notes for flashing lights and music.
- Turn the bird nest dial for clicking and chirping sounds.
- Place the 3 colored shapes in their shaped holes for sounds and flashing lights.

#### TOY SLEEP MODE

- If the toy is not played with for a period of time it will automatically shut-off to preserve battery life. Press/Touch any activity on the Treetop to resume electronic play.

**ATTENTION: NOT to be used** as a step or seat.

PRINTED IN CHINA

94966-0920



© Disney  
Based on the "Winnie the Pooh" works  
by A.A. Milne and E.H. Shepard.  
Visit the Disney website at [www.Disney.com](http://www.Disney.com)

Fisher-Price, Inc., a subsidiary of Mattel, Inc.,  
New York, New York 10010 U.S.A.  
Manufactured for Fisher-Price.  
©2002 Mattel, Inc. All Rights Reserved.  
Fisher-Price and the Fisher-Price logo are  
U.S. trademarks of Mattel, Inc.

Packaging and address should be retained for future reference:  
Mattel Canada Inc., Mississauga, Ontario L5R 3W2.  
You may call us free at 1-800-665-6288.  
Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB.  
Helpline 01628500303.

Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.  
Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.  
Diimport & Dieadarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5,  
13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817,  
Fax:03-78803867.  
Mattel, Inc., El Segundo, CA 90245 U.S.A.  
Consumer Affairs 1 (800) 524-Toys.