



SEA RESCUE™ Off-Shore Rescue Rig

2-YEAR LIMITED WARRANTY


Mattel, Inc., warrants to the original consumer purchaser that this product will be free of defects in material or workmanship for two years (unless specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052, for replacement or refund at our option.

This warranty does not cover damage resulting from unauthorized modification, accident, misuse, or abuse. In no event shall we be responsible for incidental, consequential, or contingent damages (except in those states that do not allow this exclusion or limitation). This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

Valid only in U.S.A.


Send only the product to the address above. Send all correspondence to Consumer Relations, Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245-5012, U.S.A. Or you may phone us toll-free at 1-800-524-TOYS, Monday through Friday: 8:00 a.m.-6:00 p.m. Eastern time. Outside the U.S.A., see telephone directory for Mattel listing.

Please keep these instructions for future reference as they contain important information.




APPLY LABELS AS SHOWN
HELPFUL HINT:
APPLY LABELS BEFORE ASSEMBLY.

REPAIR PATCH INCLUDED FOR INFLATABLE: In the event of an accidental puncture, cut out a suitable size patch. Make sure you round the corners of your repair patch to avoid peeling. Make sure area to be patched is clean. Press patch firmly over the puncture. Do not inflate for 20 minutes.



ASSEMBLY




UNASSEMBLED / ADULT ASSEMBLY REQUIRED

- Do not use on surfaces that can be damaged by water.
- Water toys sometimes get messy. Protect play surfaces before use.
- NOTE: After each use, drain, rinse and dry all items before storing.

2

INFLATING INSTRUCTIONS:

Non-return valves need to be slightly squeezed at bottom during inflating by mouth. Do not use a high-pressure pump.



WARNING:

CHOKING HAZARD - Small parts.
Not for children under 3 years.

