



We've Made a Change! Please use these assembly instructions in place of steps 15 and 16 in the original instructions.

Fisher-Price®

15.



16.



Now please refer back to the original instructions for additional information.