



Contents: Please remove everything from the package and compare to the contents shown here. If any items are missing, please contact your local Mattel office. Keep these instructions for future reference as they contain important information.

**WARNING:**  
CHOKING HAZARD - Small parts.  
Not for children under 3 years.

Assemble with adult guardian

Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A.  
Consumer Relations 1-800-524-8697.  
Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB.  
Helpline 01628 500303.  
Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer  
Advisory Service - 1300 135 312.  
Mattel East Asia Ltd., Room 503-09, North Tower, World  
Finance Centre, Harbour City, Tsimshatsui, HK, China.  
Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot  
13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf  
Country Resort, 47410 PJ. Malaysia. Tel:03-78803817,  
Fax:03-78803867.

**CONSUMER INFORMATION**

Need Assistance? Visit [service.mattel.com](http://service.mattel.com) or call 1-800-524-8697  
(US and Canada only).

[SERVICE.MATTEL.COM](http://SERVICE.MATTEL.COM)

To reattach

# Assembly

**X4** **X4**

• A for purple tubes.  
• B for blue tubes.  
• C for light pink tubes.  
• D for deep pink tubes.

1. Unfold inner side of tent.

2. Blue tubes **X4**

a One time snap

b **X4**

3. **X4**

4. Purple tubes **X4**

**X4**

5. Light pink tubes **X4**

**X4**

6. Deep pink tubes **X4**

6-1 **X4**

6-2 **X4**

6-3 **X4**

Outside view