



Octopod Launcher Octopod Launcher

INSTRUCTIONS


Keep these instructions for future reference as they contain important information.




HOW TO PLAY




1. Load the Gup Speeder into the launcher's loading dock.



2. Raise the two arms on the Octopod.



3. Push down on the Octo-Alert to spin the launcher. The more times you press, the faster it spins!



4. After you stop pressing, the launcher will keep spinning and then stop, launching the Gup Speeder down the ramp. Launch two Gup Speeders* and watch them race!

*Additional Gup Speeders sold separately and subject to availability. *Launcher may not work with all vehicles.

OCTONAUTS™ OCTOPOD™ Meomi Design Inc. OCTONAUTS Copyright © 2014 Vampire Squid Productions Ltd, a member of the Silvergate Media group of companies. All rights reserved. ©2013, 2014 Mattel. All Rights Reserved.

® and ™ designate U.S. trademarks of Mattel, except as noted.

PRINTED IN CHINA.

Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.



Meomi



CONSUMER ASSISTANCE
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)

service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052. Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com. Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenbad SL6 4UB. Helpline: 01628 500303. www.service.mattel.com/uk

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland. Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. New Zealand: 16:18 William Pickering Drive,