
1 Try different launch settings for best performance.

5. Rotate cannon to fire the other way.


LIGN ARROWS FOR

## **BUILD MULTIPLE LAYOUTS**




225mm Low wall

### MORE WAYS TO PLAY




### **PERFORMANCE TIPS**

- Q. My car keeps crashing on the track for no reason. What is the problem?
- A. Clear all obstructions on the track. Adjust track



- Q. My car keeps slowing down by itself on the track.
- A. Lint may collect around your car's axles. This may cause the car to run slowly. Use tweezers or a



ADD ON TO YOUR RACE WITH ADDITIONAL TRACK BUILDER STUNTS & ACCESSORIES! TO LEARN MORE ABOUT TRACK BUILDER GO TO:

HOTWHEELS.COM/TRACKBUILDER

2014 Mattel. All Rights Reserved. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Matt K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consum Visory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, Chin, mport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 410 PJ. Malaysia. Tel:03-78803817, Fax:03-78803867.



CHOKING HAZARD – Toy contains small balls and small parts. Not for children under 3 years.

Requires 4 "C" size (LR14) Alkaline batteries, not included. Dispose of battery(ies) safely.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.

2. Switch boosters ON (⇒). 3. Set cannon and load ball.

B. Release balls one by one.

TRACK BUILDER

**MEGA PACK** 

service.mattel.com HOTWHEELS.COM



6. Crank propeller full circle several times.

Warning: Do not aim at eyes or face. Only use projectiles supplied with this toy. Do not fire at point blank range. NOT FOR USE WITH SOME HOT WHEELS® VEHICLES


SIDE VIEW


TRIGGER POINT


TRIGGER POINT

## CONTENTS

# 








### **APPLY LABELS**

300mm Red low wall

225mm High wall

300mm High wall

300mm Low wall




### BATTERY INSTALLATION


- Unscrew the battery cover with a Phillips head screwdriver (not included).
- batteries (not included) in the orientation (+/-) shown.


- Replace batteries when boosters can no longer propel cars through the

## • Install 4 new "C" size (LR14) alkaline O = OFF = ON (OPPOSITE DIRECTIONS)



### **BOOSTER FEATURES**





### **ASSEMBLY**

