
#### TO PLAY 2 : FALLING CHAIR MATCH


Place chair on the platform.






## TO PLAY 3 : TRIPLE THREAT MATCH

Place another figure on the platform.





# PERFORMANCE TIPS




For best performance, align the figure's feet to the footprints on the ring. Slam the launcher harder or softer to adjust the height of your launch.




### SLAM 'N LAUNCH ARENA" INSTRUCTIONS

Please keep these instructions for future reference as they contain important information.

#### CONTENTS



# APPLY LABELS



©2014 Mattel. All Rights Reserved.

Mattel, Inc. 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697. Mattel U.K. Ltd., Vanwall BJN11-0920 Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria.

3121.Consumer Advisory Service - 1300 135 312 Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867. service.mattel.com

4



