




DELUXE PIT ROW PLAYSET INSTRUCTIONS




CONTENTS



REFER TO LETTERS MOLDED ON TOY PARTS AND THROUGHOUT THE INSTRUCTIONS TO HELP WITH ASSEMBLY.



Label Sheet



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.


©2014 Mattel. All Rights Reserved.

Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd. (993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Malaysia. Tel:03-78803817, Fax:03-78803867.




1

APPLY LABELS




2


ASSEMBLY




6 Assemble tents according to color. Check the packaging for the correct flag for each tent.




7 See the packaging for which color flag goes where.




8




9




10 Change the runway configuration.



1 Speed down the landing ramp!





2 Fuel up!



Not for use with some Planes vehicles.

3 Attach plane to spin and "fly". Detach and switch planes if desired.



4

