






# SPEED CIRCUIT SHOWDOWN™

SPIDER-MAN VS. ELECTRO




Requires 2 "D" (LR20) Alkaline batteries (not included). Dispose of batteries safely.








## **CONTENTS**




# **APPLY LABELS**



### **BATTERY INSTALLATION**

- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Install 2 new "D" size (LR20) alkaline batteries in the orientation (+/-) shown.
- Replace battery cover and tighten screw.
- Replace batteries when booster can no longer propel car through the track set.
- For best performance, use only alkaline batteries.



#### **BATTERY SAFETY INFORMATION**


In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- . Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- · Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.




Protect the environment by not disposing of this product with household waste [2002/96/EC]. Check your local authority for recycling advice and facilities.


#### **OPERATING TIPS**





Adjust track side walls at each connection point as shown.

## **ASSEMBLY**











2.

# **ASSEMBLY (CONTD.)**




### **TO PLAY**






2. Push Electro car through motorized booster and watch it speed around the track.



3. Pound button at the right time to catch Electro in the web.



©2013 Mattel. All Rights Reserved. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.