


Bi-Pod Jet

Instructions

Product Number: C1349




Figures sold separately and subject to availability.



Adult assembly is required. No tools needed for assembly.




Assembly




• "Snap" the handle into the top of the jet as shown.






 Slide the connector on the back of Rescue Heroes™ figure into the slot on the back of the seat. (Figures sold separately.)




- Grasp the claws under the front of the jet and rotate them out.
- Press the lever to open the springloaded claws.

Transform into an All-Terrain Vehicle



• Press the button on the handle to deploy the robotic legs.

Resetting the Claws and Legs



• Turn the jet over. Rotate claws and legs back into the bottom of the jet.

Care

- Wipe with a clean cloth dampened with a mild soap and water solution.
- Do not use this toy in water.

Consumer Information

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at 1-800-432-5437, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

For countries outside the United States:

CANADA Questions? 1-800-567-7724. Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2. GREAT BRITAIN Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500302. AUSTRALIA Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

NEW ZEALAND 16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.