



**Newborn**

0-3 months  
and up to 15 lb (6,8 kg) maximum



**Infant**

3-6 months  
and up to 20 lb (9 kg) maximum



**Older Baby/Toddler**

6 months+  
and up to 25 lb (11,3 kg) maximum



## CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)

1300 135 312 (Australia)

[service.fisher-price.com](http://service.fisher-price.com)

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.

Hearing-impaired consumers: 1-800-382-7470.

### Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,  
Mississauga, Ontario L5R 3W2; [www.service.mattel.com](http://www.service.mattel.com).

Great Britain: Mattel UK Ltd, Vanwall Business Park,  
Maidenhead SL6 4UB. Helpline: 01628 500303.  
[www.service.mattel.com/uk](http://www.service.mattel.com/uk)

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,  
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,  
Albany 1331, Auckland.

## Consumer Information

# **WARNING - DROWNING HAZARD**

- Babies have **DROWNED** in infant bathtubs.
- **ALWAYS** keep baby within adult's reach.
- Babies can drown in as little as 1 inch (2,5 cm) of water.
- **ALWAYS** bathe your baby using as little water as possible.
- **NEVER** allow other children to substitute for adult supervision.
- **NEVER** lift this product with baby in it.
- **NEVER** place this product in water in an adult bathtub or sink. **ALWAYS** keep the drain open in the adult bathtub or sink.
- **FALL HAZARD**
- **NEVER** use in a sink.

**IMPORTANT!** Please keep these instructions for future reference, as they contain important information.


- Please read these instructions before use of this product.
- Fit the plug into the hole in the bottom of the bathtub. Fill the bathtub with **as little water as possible** to bathe baby. **ALWAYS** test water temperature in the product **with your hand or elbow** before placing baby in this product.
- **ALWAYS** test water temperature in the product before placing baby in this product. Typical water temperature should be between 90° F (32°C) and 100° F (38°C).
- Water toys sometimes get messy. Protect play surfaces before use.
- Overfilling the bathtub may cause it to leak.
- After each use, drain and rinse all items.
- The sling is machine washable. Machine wash, cold on the gentle cycle. Do not use bleach. Tumble dry on low.

**Note:** This product may come with replacement warning labels. If English is not your primary language, select the warning label with the appropriate language and apply over the factory applied warning label.


- Product features and decoration may vary from the photographs.

**IMPORTANT!** Before each use, inspect this product for damaged hardware, loose joints, missing parts or sharp edges. **DO NOT** use if any parts are missing or broken. Contact Fisher-Price for replacement parts and instructions if needed. Never substitute parts.

# Newborn



- Fit the clips near the rounded end of the sling to the notch on each side of the wide end of the bathtub.




- Fit the short clips on the other end of the sling to the remaining notches on the other end of the bathtub.




- Place the bathtub in a larger bathtub, or place on a flat surface.
- Carefully place baby on the sling.

# Infant



- Fit the clips near the rounded end of the sling to the notch on each side of the wide end of the bathtub.




- Fit the longer clips on the other end of the sling to the remaining notches on the other end of the bathtub.



- Place the bathtub in a larger bathtub, or place on a flat surface.
- Carefully place baby on the sling.

## Older Baby



- Remove the sling from the bathtub.



- Place the bathtub in a larger bathtub, or place on a flat surface.
- Carefully place baby in the bathtub.

## Storage



### BOTTOM VIEW

- Before storing, drain, clean, rinse and dry all items.
- Fit the bottom clips into the slots in the sling.



- Hook the top clips together to hang for storage.