


INSTRUCTIONS



CITY CITY SPEEDWAY



4+

service.mattel.com

HOTWHEELS.COM

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.




CDJ34_1100274332_DOM


PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE
REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.

ASSEMBLY ADULT ASSEMBLY REQUIRED.


1.




2.





3.



4.




5.




TO PLAY


1. Working garage




2.



3. Tune your racer.




4.




TO PLAY (CONTD.)


5. Car launcher




6. Lock gate



7. Open lock for crash gate.




8.




NOT FOR USE WITH SOME HOT WHEELS® VEHICLES.

MORE WAYS TO PLAY

1.



2.



CONNECT TO OTHER HOT WHEELS® SETS (SOLD SEPARATELY).