



# 4. TO PLAY (B)

**1.** Place figures on the red and blue turnbuckles.



**2.** Pull turnbuckles back, release to launch!



**WORKS WITH DOUBLE ATTACK™ FIGURES.**

**WARNING:** Do not aim at eyes or face. Only use projectiles supplied with this toy. Do not fire at point blank range.





## TOTAL CONTROL TAKEDOWN™ PLAYSET INSTRUCTIONS

Please keep these instructions for future reference as they contain important information.



6+

## CONTENTS




RED

BLUE



## 1. APPLY LABELS



**HELPFUL HINT:** Apply labels before assembly by numbers as indicated.

©2014 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted.

Mattel, Inc. 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.


All WWE programming, talent names, images, likenesses, slogans, wrestling moves, trademarks, logos and copyrights are the exclusive property of WWE and its subsidiaries. All other trademarks, logos and copyrights are the property of their respective owners. © 2014 WWE. All Rights Reserved.

[service.mattel.com](http://service.mattel.com)




## 2. ASSEMBLY

1. Attach ring posts to the ring.




2. To attach the ropes, start from the bottom up.



**IMPORTANT:** The RED and BLUE ring posts must be attached to the launching sides of the ring.


3. Attach battle boards to the ring by colors as indicated.




**NOTE:** If desired, remove battle boards for regular ring play.

## 3. TO PLAY (A)

1. Attach Double Attack™ figures (not included) to battle boards.



2. Pull the red and blue turnbuckles to activate Double Attack™!



**WORKS WITH DOUBLE ATTACK™ FIGURES.**  
FIGURES NOT INCLUDED,  
SOLD SEPARATELY,  
SUBJECT TO AVAILABILITY.