

TO PLAY




4 / PERFORMANCE TIPS

Attach suction cups to a hard, flat surface to stabilize the set. Not suitable for use on carpet.

A. Dust and debris may slow the car down. For best performance, periodically wipe the track and wheel clean with a rag (not included).




B. Place a book under the launcher to improve performance.







WILLY'S BUTTE RIP-A-ROUND RIDGE TRACK SET INSTRUCTIONS







APPLY LABELS



©2014 Mattel. All Rights Reserved. ® and TM designate U.S. trademarks of Mattel, except as noted.

Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.


Corvette™

© Disney/Pixar www.disney.com/cars service.mattel.com

CDR38 - 1100263515G1_DOM

1

2 / ASSEMBLY



2