



Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052. Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com. Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500303.

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.
Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.
New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.

© Disney
Visit DisneyJunior.com
©2015 Mattel. All Rights Reserved.
® and ™ designate U.S. trademarks of Mattel, except as noted.

PRINTED IN CHINA.

Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.


CGJ70-0970-G1 1100370489-DOM



### Mighty Colossus

### **INSTRUCTIONS**

Keep these instructions for future reference as they contain important information.






# **ADDITIONAL PLAY PIECES**










#### **ASSEMBLY**


NOTE: Assembly steps that are marked with a star are "one-time snaps".


Press firmly until each part clicks into place.


Once these parts are put together, they cannot be taken apart.







































## 6 pages-A (Fold 2x)

Side 1

5 COVER

PRINTED IN XXXXX AXXXX, 123A567890-XXX

Side 2

2 3 4

Fold

