



3 TO PLAY 3: PLAY WITH REVVIT


A. Attach Revvit or other reptools to Ty Rux's sides!



B. Attach Revvit to Ty Rux's back, turn Revvit to hear them chat!



4 BATTERY INSTALLATION



- Batteries included are for demonstration purposes only.
- Replace the batteries if sounds become distorted or lights become dim.
- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Remove batteries and dispose of them safely.
- Install 3 AA (LR6) alkaline batteries in the orientation (+/-) shown.
- Replace battery cover and tighten screw.
- For longer life, use alkaline batteries.


BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.




Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities.




Please keep these instructions for future reference as they contain important information.

CONTENTS



I: ON
O: OFF
X: TRY ME



BOTTOM VIEW

©2015 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted.

Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.


CMX42-0970
1100651213_DOM

Dinotrux © 2015 DreamWorks Animation LLC. All Rights Reserved.




1 TO PLAY 1: LIGHTS, SOUNDS & CHOMP


A. Move Ty Rux's head left and right.




B. Lift handle up and down for lights, sounds and chomping action!



C. Go low and chomp!



D. Roll around for lights and sounds!



2 TO PLAY 2: HIDDEN STORAGE

Store Revvit and other reptools (not included) in these hidden storage!

