


HOW TO PLAY

After climbing to the top of the cliff, Thomas makes a sharp, 360° turn.


As Thomas turns, he knocks over the boulders to reveal surprises underneath.



CLOSE CALL CLIFF SET

INSTRUCTIONS

Keep these instructions for future reference as they contain important information.



BATTERY INFORMATION


BATTERY INSTALLATION

- Access the battery compartment by unscrewing and separating the top half of the engine from the bottom half of the engine.
- Install the batteries as indicated inside the battery compartment.
- Re-assemble the two halves of the engine, re-insert the screw, and tighten.
- If the engine begins to operate erratically, you may need to reset the electronics by removing the batteries from the engine and reinstalling them.
- Requires 2 "AAA" (LR03) batteries.
- For longer life use only alkaline batteries.

BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.




REQUIRED TOOL:
PHILLIPS SCREWDRIVER
(NOT INCLUDED).

Protect the environment by not disposing of this product with household waste (2012/19/EU). Check your local authority for recycling advice and facilities.


Thomas the Tank Engine & Friends™
CREATED BY BRIT™ ALLCROFT
Based on the Railway Series by The Reverend W Awdry.
©2015 Gullane (Thomas) Limited. Thomas the Tank Engine & Friends and Thomas & Friends are trademarks of Gullane (Thomas) Limited.
©2015 HIT Entertainment Limited. HIT and the HIT logo are trademarks of HIT Entertainment Limited.
©2015 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. **PRINTED IN CHINA.**
Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500.

FisherPrice®

WHAT'S INCLUDED



HELPFUL HINTS



Track marking codes are found on the bottom of tracks.

ADULT ASSEMBLY REQUIRED.
No tools needed.


Note:
May not work with all engines.

CAUTION:
To prevent entanglement,
keep hair away from wheels.


DFM51
CFF94 Asst.
DFM51-0970-G1
1100626240-DOM

CONSUMER ASSISTANCE
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)
service.fisher-price.com
Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.
Outside the United States:
Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.
Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk
Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.
Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.
New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

Item No : DFM51-0970-G1 / 1100626240-DOM
Blank Size : A3
Paper : Recycle Paper, 70 gsm
Color : Black
Date : Jul, 21, 2015 (Lily Liang)



ASSEMBLY



TRACK LAYOUT

