



HOW TO PLAY




Place one cargo piece in Percy's cargo car.




The engine bursts through the Tunnel!



As the engine reaches the Sorting Station, his special cargo car automatically dumps the shipment down the chute.



As the engine passes, he will cause the spooky haystack to transform!



Use the stop-track to stop the engine, load the cargo into the cargo car, flip the switch and send him on his way!

* The engine should move forward in the direction of the arrow.

CAUTION:
To prevent entanglement,
keep hair away from wheels.

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

BATTERY INFORMATION

BATTERY INSTALLATION


- Access the battery compartment by unscrewing and separating the top half of the engine from the bottom half of the engine.
- Install the batteries as indicated inside the battery compartment.
- Re-assemble the two halves of the engine, re-insert the screw, and tighten.
- If the engine begins to operate erratically, you may need to reset the electronics by removing the batteries from the engine and reinstalling them.
- Requires 2 "AAA" (LR03) batteries.
- For longer life use only alkaline batteries.



Protect the environment by not disposing of this product with household waste (2012/19/EU). Check your local authority for recycling advice and facilities.

BATTERY SAFETY INFORMATION

- In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:
- Non-rechargeable batteries are not to be recharged.
 - Rechargeable batteries are to be removed from the product before being charged.
 - Rechargeable batteries are only to be charged under adult supervision.
 - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
 - Do not mix old and new batteries.
 - Only batteries of the same or equivalent type as recommended are to be used.
 - Batteries are to be inserted with the correct polarity.
 - Exhausted batteries are to be removed from the product.
 - The supply terminals are not to be short-circuited.
 - Dispose of battery(ies) safely.
 - Do not dispose of this product in a fire. The batteries inside may explode or leak.



CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)
1300 135 312 (Australia)

service.fisher-price.com

Outside the United States:
Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.
Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500303. www.service.mattel.com/uk
Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.
Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.
New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

Thomas the Tank Engine & Friends™

CREATED BY BRITT ALLCROFT

Based on the Railway Series by The Reverend W Awdry.
©2016 Gullane (Thomas) Limited. Thomas the Tank Engine & Friends and Thomas & Friends are trademarks of Gullane (Thomas) Limited.
©2016 HIT Entertainment Limited. HIT and the HIT logo are trademarks of HIT Entertainment Limited.

©2016 Mattel. All Rights Reserved.
* and ™ designate U.S. trademarks of Mattel, except as noted.
PRINTED IN CHINA.
Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500.




PERCY'S MIDNIGHT MAIL DELIVERY




Keep these instructions for future reference as they contain important information.

WHAT'S INCLUDED



HELPFUL HINTS



Track marking codes are found on the bottom of tracks.



ONE-TIME SNAPS: Assembly step that is marked with a star is "one-time snap". Once this part is put together, it cannot be taken apart.

ADULT ASSEMBLY REQUIRED.






No tools needed.

Note: Some engines may not work on this track set.

Note:

- Glow-in-the-dark feature will last longer if you do not expose this product to intense heat or direct sunlight for prolonged periods of time.
- Place product approximately 5 feet (152 cm) away from a light source for 30 seconds. Placing tracks closer will not intensify the "glow-in-the-dark" feature

ASSEMBLY



TRACK LAYOUT

