



Flaming Volcano Jump Playset

INSTRUCTIONS




Keep these instructions for future reference as they contain important information.

DGK85-0970
1100624426-DOM

PARTS / LABEL PLACEMENT

Assembly Parts

Label Placement











Push to connect.

TRACK LAYOUT



ASSEMBLY





HOW TO PLAY



1. Load the vehicle into the launcher.



2. Slide the rock-shaped button down and release to cause the ring of flame to start spinning. The more you press, the longer it spins.



3. Slam down on the back of the launchers with your fist to race.



4. Launch the vehicle through the spinning flame!



5. You can load and launch 2 vehicles at one time. (Second vehicle sold separately.)

Fisher-Price®

© 2015 Viacom International Inc. All Rights Reserved. Nickelodeon, Blaze and the Monster Machines and all related titles, logos and characters are trademarks of Viacom International Inc.

©2015 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. **PRINTED IN CHINA.**

Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500.

CONSUMER ASSISTANCE
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)
service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500303. www.service.mattel.com/uk

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.