



Thomas Bath Crayons



INSTRUCTIONS

Keep these instructions for future reference as they contain important information.

HELPFUL HINTS

ATTENTION: Intended for bathtub use only. Adult supervision recommended.

Not recommended for use in older tubs that are in poor condition.

Product may stain or stick to fabrics and other surfaces, including certain porous surfaces such as grout between tiles.

Water toys sometimes get messy. Protect play areas before use.

Avoid contact with carpet, clothing, walls, and furniture.

Test for washability on a small area before using in your tub.

Wash any color residue thoroughly from skin after use and before using a towel.

Drain, rinse, clean and dry all items thoroughly before storing. Crayons should be stored in the slots in Thomas' rear coal bin.

Crayon refills available while supplies last.

To order, please visit service.fisher-price.com or call 1-800-432-5437 (US & Canada)



CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)
1300 135 312 (Australia)

service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park,
Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.

Thomas the Tank Engine & Friends™



CREATED BY BRIT ALLCROFT

Based on the Railway Series by The Reverend W Awdry.

©2015 Gullane (Thomas) Limited. Thomas the Tank Engine & Friends and Thomas & Friends are trademarks of Gullane (Thomas) Limited.

©2015 HIT Entertainment Limited. HIT and the HIT logo are trademarks of HIT Entertainment Limited.

©2015 Mattel. All Rights Reserved.

* and ™ designate U.S. trademarks of Mattel, except as noted.

PRINTED IN CHINA. Mattel East Asia Ltd.,
Room 503-09, North Tower, World Finance Centre,
Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500.



HIT entertainment

DGL05-0970
1100691080-DOM

Fisher-Price®

HOW TO PLAY




1

Pull out Thomas' funnel from his smoke box and place a crayon into it, as shown. Note: The crayon holder works best with new crayons as the size of the crayons will reduce after being played with in water.



2

Slide the crayon into Thomas' smoke box.



3

Use the No.1 blue engine to draw on the bathtub.



4


Note: Once a crayon is in the holder, you can also draw on the tub without the Thomas engine.

STORAGE



1

Pull out the steam cloud and funnel from Thomas' smoke box.



2

Remove the crayon from the holder gently and store it in the slot in Thomas' rear coal bin.