
## FOR FIRST TIME USE

If the latch to open the viewer is TOO LOOSE with your phone inserted, then attach the included foam pads where indicated for a better fit.

**OPEN VIEWER** 



APPLY FOAM PADS



If the latch on your viewer is DIFFICULT TO OPEN, apply pressure on both halves of the viewer when opening the latch.

SQUEEZE VIEWER
WHILE OPENING



**OPEN VIEWER** 



www.view-master.com/troubleshooting