


SURVIVAL MODE PLAYSET

INSTRUCTIONS

6+

CONTENTS

Playset Interchangeable Pieces



Diamond Pickaxe



Crafting table



2 Diamonds (spare)




5 Sand Blocks



8 Torches



1 Ladder



1 Sticker Sheet.

Apply stickers anywhere you like!
The labels are one time use only and cannot be repositioned.



Check out service.mattel.com for more information.
Please remove everything from the package and compare to the contents shown here.
If any items are missing, please contact your local Mattel office.
Keep these instructions for future reference as they contain important information.
Colors and decorations may vary.

©2016 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.




DNM76-0970-G3
1100957362-DOM

service.mattel.com


BEFORE YOU START

SET UP


ONE TIME ASSEMBLY! Snap these parts on BEFORE crafting.



DETACHABLE ELEVATOR



IMPORTANT: Mountain Top cannot be detached once assembled.




ONE TIME ASSEMBLY!

CRAFT THIS COMBINATION! 50+ COMBINATIONS TO EXPLORE!



Mountain

Mountain Base



Base

Doorway


1 Sand Block

House

BASE PLAY FEATURES

ELEVATOR

Move figure up and down on the elevator!




BOTTOM VIEW



Figures sold separately.

WATERFALL/LAVA FLOW


Move block left or right to change between Waterfall and Lava Flow!



DIAMOND


Find the hidden slot in the base.

Store the diamond in the hidden slot.



Close slot.

Find the hidden diamond!



Figures sold separately.

HIDDEN ZOMBIE


There is a hidden Zombie in the base!
Locate and push the box down to find it!



DOORWAY PLAY FEATURES

SAND BLOCKS

Use sand blocks in your combinations!
Try blocking off the doorway with sand blocks!



MOUNTAIN PLAY FEATURES

TORCHES

Attach torches to mountain top and craft a torch tower!



Torches can also be attached to any pieces with this slot.



HOUSE PLAY FEATURES


DOOR

Enter the house through the door.



LADDER

The ladder can be connected to any pieces with these 2 slots.



CRAFTING TABLE


USE THE DIAMOND TO "CREATE" A DIAMOND PICKAXE!

1. Open the Crafting Table.

2. Place diamond in the slot.

3. Press on the diamond and close Crafting Table.



4. Open Crafting Table again to find the Diamond Pickaxe!




5. Place Diamond Pickaxe back in the Crafting Table.

6. Press Diamond Pickaxe and close Crafting Table to reset.

7. Hide the Crafting Table behind the door!



TRY CRAFTING ANOTHER COMBINATION!



50+ COMBINATIONS TO EXPLORE! CAN YOU CRAFT THEM ALL?

USE THE INTERCHANGEABLE PIECES AND CRAFT 50+ COMBINATIONS!

