

# INSTRUCTIONS

Fisher-Price®  
 **SMART TOY**®

SMART CARDS

# WHAT DO YOU WANT TO DO NEXT?

## **Before using your new Smart Cards for the first time:**

- Download and connect Smart Toy to the parent app (if you haven't already).  
Go to: <http://www.smarttoy.com/app>
- Make sure Smart Toy is being used where you initially connected it to Wi-Fi.

Keep these instructions for future reference, as they contain important information.



**service.fisher-price.com**

**UNITED STATES**

1-800-432-5437

Fisher-Price, Inc. 636 Girard Avenue, East Aurora, NY 14052

Hearing-impaired consumers: 1-800-382-7470

**CANADA**

1-800-432-5437

Mattel Canada Inc. 6155 Freemont Blvd.

Mississauga, Ontario L5R 3W2

© & ™ Mattel and Smart Toy LLC. All Rights Reserved.

® and ™ designate U.S. trademarks of Mattel, except as noted.

**PRINTED IN CHINA**

**DNV53-0970  
1100922421-DOM**