




MINECRAFT

GHAST ATTACK TRACK®



4+  **MOJANG**

© & TM Notch Development AB and Mojang AB. All Rights Reserved.

service.mattel.com

HOTWHEELS.COM



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.




DPW28-0970G1
1100923809-DOM


PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE
REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.

CONTENTS


GHAST




MINECART RAILS




RAIL LOOP STAGE



MINECART & FIGURE









LAUNCHER




ASSEMBLY




Refer to letter on toy parts and contents page to help with assembly.




7.




8.




9.




10.



11.




12. Connect to other HOT WHEELS® sets (sold separately).




TO PLAY


- 1. MOVE LAUNCHER SO IT POINTS TO THE LEFT MINECART RAIL, LOAD MINECART AND PULL LAUNCHING ROD BACK TO LOCK IN PLACE.**




- 2. LAUNCH THROUGH THE LOOP AND GHAST TO WAKE IT UP!**




- 3. LAUNCH THROUGH THE LOOP AND GHAST AGAIN TO OPEN ITS MOUTH!**



4. MOVE LAUNCHER SO IT POINTS TO THE RIGHT MINECART RAIL.




5. LAUNCH AND HIT THE OPEN MOUTH TO BLAST THE GHAST!



RESET

1.



2.

