

Fisher-Price®

DWL34

**SLIDE
& SPELL**



**GRASP
& WRITE**




**ERASE
& REPEAT**



ADULT ASSEMBLY REQUIRED.

You can create additional letter tiles. Remove a letter from the label sheet and apply to a blank tile. For best results, avoid repositioning a label once it has been applied.



THINK & LEARN

Alpha *Slide* Writer™



CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)
1300 135 312 (Australia)



service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.

Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park,
Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.



CAUTION

This package contains small parts.
For adult assembly only.

**Keep this instruction sheet for future
reference as it contains important information.**